



R10274716

ISSUED BY
RPP-WTP PDC
15 3/21/04
DATE

Document title:

System Logic Description for High-Level Waste Facility - Melter Offgas Treatment Process and Process Vessel Vent Extraction (HOP and PVV) Systems

Contract number: DE-AC27-01RV14136
Department: Controls and Instrumentation
Author(s): Anthony L. Coulam

Principal author
signature:

Anthony L. Coulam

Document number: 24590-HLW-PER-J-02-001, Rev 2

Checked by: Robert O. Frink

Checker signature:

Robert O. Frink

Date of issue: 25 MARCH 2004


Issue status: Issued for Permitting Use

Approved by: Stephen E. Anderson

Approver's position: C&I Discipline Engineering Manager

Approver signature:

S. E. Anderson



This bound document contains a total of 18 sheets

River Protection Project
Waste Treatment Plant
2435 Stevens Center Place
Richland, WA 99352
United States of America
Tel: 509 371 2000

Notice

Please note that source, special nuclear and byproduct materials, as defined in the Atomic Energy Act of 1954 (AEA), are regulated at the US Department of Energy (DOE) facilities exclusively by DOE acting pursuant to its AEA authority. DOE asserts that pursuant to the AEA, it has sole and exclusive responsibility and authority to regulate source, special nuclear, and byproduct materials at DOE-owned nuclear facilities. Information contained herein on radionuclides is provided for process description purposes only.

History Sheet

| Rev | Date | Reason for revision | Revised by |
|-----|------------------|---|------------|
| 0 | 29 October 2002 | Issued for permitting use | N McAdams |
| 1 | 04 December 2003 | Major revision, issued for permitting use | A Coulam |
| 2 | 25 MARCH 2004 | Issued for permitting use | A Coulam |

Contents

| | |
|---|----------|
| Notice | ii |
| History Sheet..... | iii |
| Glossary..... | vii |
| 1 Introduction..... | 1 |
| 2 Applicable Documents | 1 |
| 3 Description..... | 2 |
| 3.1 Melter 1 and 2 Submerged Bed Scrubbers (SBS) | 2 |
| 3.2 Melter 1 and 2 SBS Condensate Receiver Vessels..... | 3 |
| 3.3 Melter 1 and 2 Wet Electrostatic Precipitators (WESP) | 3 |
| 3.4 Melter 1 and 2 High Efficiency Mist Eliminators (HEME)..... | 4 |
| 3.5 Melter 1 and 2 High Efficiency Particulate Air (HEPA) Filters | 4 |
| 3.6 Process Vessel Vent Extraction (PVV) System..... | 4 |

Tables

| | | |
|----------------|--|----------|
| Table 1 | Associated ITS Instruments for Melter 1 and 2 Submerged Bed Scrubbers (SBS)..... | 5 |
| Table 2 | Associated ITS Instruments for Melter 1 and 2 SBS Condensate Receiver Vessels..... | 5 |
| Table 3 | Associated Instruments for Melter 1 and 2 Wet Electrostatic Precipitators (WESP)..... | 5 |
| Table 4 | Associated Instruments for Melter 1 and 2 High Efficiency Mist Eliminators (HEME)..... | 5 |
| Table 5 | Associated Instruments for Melter 1 and 2 High Efficiency Particulate Air (HEPA) Filters..... | 5 |

Figures

| | | |
|-----------------|--|-----------|
| Figure 1 | Typical ITS Level Measurement For Melter 1 And 2 Submerged Bed Scrubbers | 7 |
| Figure 2 | Typical ITS Level Measurement For Melter 1 And 2 SBS Condensate Receiver Vessels..... | 8 |
| Figure 3 | Typical Level Measurement For Melter 1 And 2 Wet Electrostatic Precipitators (WESP)..... | 9 |
| Figure 4 | Typical Level Measurement For Melter 1 And 2 High Efficiency Mist Eliminators (HEME)..... | 10 |

Figure 5 Typical Pressure Differential Measurement For Melter 1 And 2 High
Efficiency Particulate Air (HEPA) Filters11

Acronyms and Abbreviations

Reference the piping and instrumentation diagrams (P&IDs) symbols and legend sheets as listed in the Applicable Documents section, for acronyms and abbreviations used in the figures.

| | |
|------|---|
| AI | analog input |
| HEME | high efficiency mist eliminator |
| HLW | high level waste |
| HOP | melter offgas treatment process system |
| ITS | important to safety |
| LAH | level alarm high |
| LAHH | level alarm high high |
| LI | level indicator |
| LSH | level switch high |
| LSHH | level switch high high |
| LT | level transmitter |
| P&ID | piping and instrumentation diagram |
| PDAH | pressure differential alarm high |
| PDSH | pressure differential switch high |
| PVV | process vessel vent extraction system |
| RFD | reverse flow diverter |
| RLD | radioactive liquid waste disposal system |
| SBS | submerged bed scrubber |
| VSL | vessel |
| WESP | wet electrostatic precipitator |
| WTP | Hanford Tank Waste Treatment and Immobilization Plant |

Glossary

| | |
|--------------------|--|
| Batch control | This term refers to control activities and control functions that provide an ordered set of processing activities to complete a batch process. |
| Batch process | A batch process leads to the production of a finite quantity of material by subjecting quantities of input material to an ordered set of processing activities over a finite period using one or more pieces of equipment. |
| Control system | This term refers to electronic processors that perform regulatory and logic control functions necessary for normal operation of the plant. |
| Exception handling | This term refers to those functions that deal with plant or process contingencies and other events that occur outside the normal or desired behavior of batch control. |
| High level | This term refers to a notification in the control system that is activated when the high level setpoint of the vessel has been reached. |
| High-high level | This term refers to a notification in the control system that is activated when the high-high level setpoint of the vessel has been reached. |
| Interlock | Predetermined system equipment connections so that action of one part of the system affects the action of another part of the system. |
| Low level | This term refers to a notification in the control system that is activated when the low level setpoint of the vessel has been reached. |
| Low-low level | This term refers to a notification in the control system that is activated when the low-low level setpoint of the vessel has been reached. |

1 Introduction

This document describes the instrument control logic for dangerous waste vessels and ancillary equipment associated with the high-level waste (HLW) facility melter offgas treatment process (HOP) and process vessel vent extraction (PVV) systems as they pertain to the dangerous waste permit.

2 Applicable Documents

24590-WTP-M6-50-P0001, *P&ID Symbols and Legend Sheet 1 of 6*

24590-WTP-M6-50-P0002, *P&ID Symbols and Legend Sheet 2 of 6*

24590-WTP-M6-50-P0003, *P&ID Symbols and Legend Sheet 3 of 6*

24590-WTP-M6-50-P0004, *P&ID Symbols and Legend Sheet 4 of 6*

24590-WTP-M6-50-P0005, *P&ID Symbols and Legend Sheet 5 of 6*

24590-WTP-M6-50-P0006, *P&ID Symbols and Legend Sheet 6 of 6*

24590-HLW-M6-HOP-P0001, *P&ID-HLW Melter Offgas System Melter 1 Primary Offgas Scrubber*

24590-HLW-M6-HOP-P0002, *P&ID-HLW Melter Offgas System Melter 1 Primary Offgas WESP*

24590-HLW-M6-HOP-P0004, *P&ID-HLW Melter 1 Offgas Fluidic Air Rack HOP-RK-00025 (Q)*

24590-HLW-M6-HOP-P0006, *P&ID-HLW Melter Offgas System Melter 1 Primary Offgas Scrubber (Q) Condensate Vessel*

24590-HLW-M6-HOP-P0009, *P&ID-HLW Melter Offgas System Melter 1 Primary Offgas HEME*

24590-HLW-M6-HOP-P0010, *P&ID-HLW Melter Offgas System Melter 1 Primary Offgas HEPA Filters*

24590-HLW-M6-HOP-P20001, *P&ID-HLW Melter Offgas System Melter 2 Primary Offgas Scrubber*

24590-HLW-M6-HOP-P20002, *P&ID-HLW Melter Offgas System Melter 2 Primary Offgas WESP*

24590-HLW-M6-HOP-P20004, *P&ID-HLW Melter 2 Offgas Fluidic Air Rack HOP-RK-00048*

24590-HLW-M6-HOP-P20006, *P&ID-HLW Melter Offgas System Melter 2 Primary Offgas Scrubber Condensate Vessel*

24590-HLW-M6-HOP-P20009, *P&ID-HLW Melter Offgas System Melter 2 Primary Offgas HEME*

24590-HLW-M6-HOP-P20010, *P&ID-HLW Melter Offgas System Melter 2 Primary Offgas HEPA Filters*

24590-HLW-M6-PVV-P0001, *P&ID-HLW Process Vessel Vent Extraction System*

24590-HLW-M6-PVV-P20001, *P&ID-HLW Melter 2 Process Vessel Vent Extraction System*

24590-HLW-3YD-HOP-00001, *Systems Description for HLW Melter Offgas Treatment Process and Process Vessel Vent Extraction (HOP and PVV Systems)*

3 Description

The HLW HOP system plant items and ancillary equipment included in the dangerous waste permit are the following:

- HOP-SCB-00001 melter 1 submerged bed scrubber (SBS)
- HOP-SCB-00002 melter 2 submerged bed scrubber (SBS)
- HOP-VSL-00903 SBS condensate receiver vessel
- HOP-VSL-00904 melter 2 SBS condensate receiver vessel
- HOP-WESP-00001 melter 1 wet electrostatic precipitator (WESP)
- HOP-WESP-00002 melter 2 wet electrostatic precipitator (WESP)
- HOP-HEME-00001A melter 1 high efficiency mist eliminator (HEME)
- HOP-HEME-00001B melter 1 high efficiency mist eliminator (HEME)
- HOP-HEME-00002A melter 2 high efficiency mist eliminator (HEME)
- HOP-HEME-00002B melter 2 high efficiency mist eliminator (HEME)
- HOP-HEPA-00001A primary offgas HEPA filter
- HOP-HEPA-00002A primary offgas HEPA filter
- HOP-HEPA-00001B primary offgas HEPA filter
- HOP-HEPA-00002B primary offgas HEPA filter
- HOP-HEPA-00007A primary offgas HEPA filter, melter 2
- HOP-HEPA-00008A primary offgas HEPA filter, melter 2
- HOP-HEPA-00007B primary offgas HEPA filter, melter 2
- HOP-HEPA-00008B primary offgas HEPA filter, melter 2

The HLW PVV system does not contain any plant items or ancillary equipment included in the dangerous waste permit.

3.1 Melter 1 and 2 Submerged Bed Scrubbers (SBS)

The offgas from the HLW melter with film cooler and pressure control air is transferred via the primary offgas jumpers for further cooling and treatment in the submerged bed scrubbers (SBS) (HOP-SCB-00001 and HOP-SCB-00002). Each SBS removes particulates and cools the offgas to a desired discharge temperature by quenching the offgas with a solution and transferring the heat out using cooling coils and cooling jacket. The SBS levels are controlled by overflows into the SBS condensate receiver vessels (HOP-VSL-00903 and HOP-VSL-00904). There is redundant safety system level detection within the SBSs so that high-high liquid levels can be detected and the corresponding melter feed, reverse flow diverters (RFDs) in the SBS condensate receiver vessel and all controlled feeds into the SBS can be terminated. The scrubbed offgas discharges through the top of the SBSs for further treatment. Agitation

in the SBSs is maintained by solution jets powered by RFDs located in the SBS condensate receiver vessels. The agitation maintains the solids in the SBSs tank bottom in suspension so that solid slurry can be periodically removed by air jet activated siphon lines that draw slurry through the suction square to the acidic waste vessel (RLD-VSL-00007). Condensate is circulated between the SBS and the SBS condensate receiver vessel by pumping the solution using the RFDs.

The SBS liquid levels are maintained at nominal levels by fixed overflows to the SBS condensate receiver vessels. Condensate and particulates are removed from the systems by regular operational batch transfers from the SBSs to the acidic waste vessel (RLD-VSL-00007). Transfers maintain the SBS condensate receiver vessels within the acceptable operating range. When the operator initiates the transfer-out sequence, the control system will verify that instruments, utilities, and equipment associated with the transfer are within operational parameters. If any of the monitored parameters are not within the specified limits during the transfer, the control system will switch to exception handling logic. The control system alarms or notifies the operator upon reaching the high, high-high, low, or low-low liquid levels.

When the levels are no longer within the normal operating range, interlocks in the programmable protection system overrides operation to control high-high liquid level conditions. Figure 1 shows the interlocks for the important to safety (ITS) level instruments in Table 1, which are associated with the SBSs.

3.2 Melter 1 and 2 SBS Condensate Receiver Vessels

The SBS condensate receiver vessels (HOP-VSL-00903 and HOP-VSL-00904) receive the condensate overflows from the SBSs, drainage from the wet electrostatic precipitators (WESP), and drainage from the high-efficiency mist eliminators (HEME). To help minimize the buildup of solids in the bottom of the SBSs, solution jets powered by RFDs in the SBS condensate receiver vessels are used to agitate the solution at the bottom of the SBSs. The agitation maintains the solids in the tank bottoms suspended so that they can be periodically removed by air jet activated siphon lines that draw slurry through the suction square in the SBSs to the acidic waste vessel (RLD-VSL-00007). Condensate is continuously circulated between the SBS condensate receiver vessels and the SBSs with the RFDs. Like the SBSs, there is redundant safety system level detection within the SBS condensate receiver vessels so that high-high liquid levels can be detected and the corresponding melter feed, water sprays to the WESP and HEME and all controlled feeds into the SBS condensate receiver vessel can be terminated. Because the SBSs operate at a constant level, the condensate builds up in the SBS condensate receiver vessels. The operator will initiate a liquid waste transfer from the SBS to the acidic waste vessel (RLD-VSL-00007) to maintain the SBS condensate receiver vessel within the acceptable operating range. The control system alarms or notifies the operator upon reaching the high, high-high, low or low-low liquid levels.

When the levels are no longer within the normal operating range, interlocks in the programmable protection system overrides operation to control high-high liquid level conditions. Figure 2 shows the interlocks for the ITS level instruments in Table 2, which are associated with the SBS condensate receiver vessels.

3.3 Melter 1 and 2 Wet Electrostatic Precipitators (WESP)

The SBSs offgas are routed to the corresponding WESPs (HOP-WESP-00001 and HOP-WESP-00002) for removal of aerosols and particulates down to a submicron size. The WESPs house vertical tubes, which act as positive electrodes. Each of these tubes also has a single negatively charged electrode, which runs down the centerline. The strong electric field, generated by the discharge electrode, generates

electrons that apply a negative charge to the offgas particles (corona effect). The negatively charged particles are then attracted to the positively charged tube walls. The collected particles are partially washed from the tube wall by entrained condensate that also collects on the inner tube wall. The solids are periodically washed from the tubes using water sprays from above the tubes. The water and collected particulates drains into the SBS condensate receiver vessels.

The WESPs will not be expected to have liquid level accumulation during normal operations. Figure 3 shows the indication for the level instruments in Table 3, which are associated with the WESPs. If liquid starts to accumulate in the WESPs during normal operations, the liquid level indication will alert the operator.

3.4 Melter 1 and 2 High Efficiency Mist Eliminators (HEME)

The purpose of the HEMEs (HOP-HEME-00001A, HOP-HEME-00001B, HOP-HEME-00002A, and HOP-HEME-00002B) is to further remove aerosols from the HLW melter offgas and the vessel ventilation air, and to reduce the solids-loading rate on the HEPA filters. As the offgas passes through the HEMEs, the liquid droplets and other aerosols in the offgas interact and adhere to the filaments by surface tension. The droplets agglomerate and eventually acquire enough mass to gravity flow to the bottom of the unit and drain into the SBS condensate receiver vessels. As the condensate flows down through the filter bed, a washing action is generated that will help wash and dissolve collected solids from the filter elements.

The HEMEs will not be expected to have liquid level accumulation during normal operations. Figure 4 shows the indication for the level instruments in Table 4, which are associated with the HEMEs. The liquid level indication will alert the operator that liquid is accumulating in the HEMEs.

3.5 Melter 1 and 2 High Efficiency Particulate Air (HEPA) Filters

The purpose of the high efficiency particulate air (HEPA) filters is to provide high efficiency submicron particulate removal. The HEPA filters will be periodically tested for particulate removal efficiency to validate performance. Figure 5 shows the indication for the pressure differential instruments in Table 5, which are associated with the HEPA filters.

3.6 Process Vessel Vent Extraction (PVV) System

The process vessel vent (PVV) system provides a vacuum on connected tanks relative to the tanks surroundings. The header is connected in the melter cave to the primary offgas system between the WESP and HEME, which provides the vacuum source. There is no figure or table associated with this system.

Table 1 Associated ITS Instruments for Melter 1 and 2 Submerged Bed Scrubbers (SBS)

| Instrument Number | Associated Vessel | Description |
|-------------------|-------------------|--------------------------------|
| HOP-LT-0104 | HOP-SCB-00001 | Safety control level |
| HOP-LT-0130 | HOP-SCB-00001 | Redundant safety control level |
| HOP-LT-2104 | HOP-SCB-00002 | Safety control level |
| HOP-LT-2130 | HOP-SCB-00002 | Redundant safety control level |

Table 2 Associated ITS Instruments for Melter 1 and 2 SBS Condensate Receiver Vessels

| Instrument Number | Associated Vessel | Description |
|-------------------|-------------------|--------------------------------|
| HOP-LT-0110 | HOP-VSL-00903 | Safety control level |
| HOP-LT-0136 | HOP-VSL-00903 | Redundant safety control level |
| HOP-LT-2110 | HOP-VSL-00904 | Safety control level |
| HOP-LT-2136 | HOP-VSL-00904 | Redundant safety control level |

Table 3 Associated Instruments for Melter 1 and 2 Wet Electrostatic Precipitators (WESP)

| Instrument Number | Associated Vessel | Description |
|-------------------|-------------------|-------------|
| HOP-LT-0208 | HOP-WESP-00001 | Level |
| HOP-LT-2208 | HOP-WESP-00002 | Level |

Table 4 Associated Instruments for Melter 1 and 2 High Efficiency Mist Eliminators (HEME)

| Instrument Number | Associated Vessel | Description |
|-------------------|-------------------|-------------|
| HOP-LT-0216 | HOP-HEME-00001A | Level |
| HOP-LT-0229 | HOP-HEME-00001B | Level |
| HOP-LT-2216 | HOP-HEME-00002A | Level |
| HOP-LT-2229 | HOP-HEME-00002B | Level |

Table 5 Associated Instruments for Melter 1 and 2 High Efficiency Particulate Air (HEPA) Filters

| Instrument Number | Associated Vessel | Description |
|-------------------|-------------------|-----------------------|
| HOP-PDT-0222 | HOP-HEPA-00001A | Pressure differential |
| HOP-PDT-0223 | HOP-HEPA-00002A | Pressure differential |
| HOP-PDT-0235 | HOP-HEPA-00001B | Pressure differential |
| HOP-PDT-0236 | HOP-HEPA-00002B | Pressure differential |
| HOP-PDT-2222 | HOP-HEPA-00007A | Pressure differential |
| HOP-PDT-2223 | HOP-HEPA-00008A | Pressure differential |

24590-HLW-PER-J-02-001, Rev 2
System Logic Description for High-Level Waste Facility
- Melter Offgas Treatment Process and Process Vessel
Vent Extraction (HOP and PVV) Systems

| | | |
|--------------|-----------------|-----------------------|
| HOP-PDT-2235 | HOP-HEPA-00007B | Pressure differential |
| HOP-PDT-2236 | HOP-HEPA-00008B | Pressure differential |

Figure 1 Typical ITS Level Measurement For Melter 1 And 2 Submerged Bed Scrubbers




Figure 2 Typical ITS Level Measurement For Melter 1 And 2 SBS Condensate Receiver Vessels




Figure 3 Typical Level Measurement For Melter 1 And 2 Wet Electrostatic Precipitators (WESP)




Figure 4 Typical Level Measurement For Melter 1 And 2 High Efficiency Mist Eliminators (HEME)




Figure 5 Typical Pressure Differential Measurement For Melter 1 And 2 High Efficiency Particulate Air (HEPA) Filters

